

System Plus



System Plus vereinigt funktionale Vorzüge mit einer klaren Form. Sämtliche Serviceteile sind platzsparend stapelbar. Verstärkte Kanten machen das Porzellan unempfindlich gegenüber alltäglichen Konfrontationen. Salamander, Mikrowelle, Spülmaschine – das robuste System Plus übersteht auch den härtesten Alltag ohne Blessuren. Alles in allem: funktional und flexibel.

System Plus features both superb functions and clear contours. All the parts in the set can be stacked to save space, and reinforced edges ensure that this porcelain emerges from life's daily arduous unscathed. Open grills, microwaves, dishwashers – even the most trying situations leave this robust porcelain unmarked. All in all, it's beautifully functional.

weiß/white 90-011



Zwei Farblinie / -band
two colour lines

3 mm

Studentenwerk / Student Union
Jena-Weimar, Mensa Carl-Zeiss-Promenade

System Plus



Sound

dunkelblau / dark blue 72-242
schwarz / black 70-482
rot / red 70-445

Landlook

73-959



Farblinie /-band colour line

70-586





System Plus



Navajo Life

73-827

REFERENZ

REFERENCE

Individualisiertes Porzellan für / Individualized porcelain for
Café-NB-Dinner-Bar, Halle auf / on System Plus



Cocktail Plus

orange 73-811
blaugrau / blue grey 73-810
grün / green 73-812
gelb / yellow 73-813
dunkelblau / dark blue 73-556
ocker / ochre 73-557
rot / red 73-558
grau / grey 73-559





Espresso-Obertasse, stapelbar
espresso cup, stackable
0,09 l
Art. Nr. 11 5405



Kaffee-Obertasse, stapelbar, hoch
coffee cup, stackable, tall
0,18 l
Art. Nr. 11 5414



Kaffee-Obertasse, stapelbar
coffee cup, stackable
0,18 l
Art. Nr. 11 5406



Cappuccino-Obertasse, stapelbar
cappuccino cup, stackable
0,22 l
Art. Nr. 11 5407



Schoko-Obertasse
chocolate mug
0,22 l
Art. Nr. 20 4706



Kaffeebecher, stapelbar
coffee mug, stackable
0,28 l
Art. Nr. 11 5305



Espresso-Untertasse
saucer
13 cm
Art. Nr. 11 3502



Kombi-Untertasse
saucer
15 cm
Art. Nr. 11 3504



Kaffeekanne, komplett
coffee pot (with cover)
0,30 l
Art. Nr. 11 1113

Deckel zur Kaffeekanne
cover for coffee pot
Art. Nr. 11 1311



Teeanne, komplett
tea pot (with cover)
0,40 l
Art. Nr. 11 1406

Deckel zur Teeanne
cover for tea pot
Art. Nr. 11 1311



Milchkännchen
milk jug
0,15 l
Art. Nr. 11 1002



Zuckerdose, komplett
sugar bowl with cover
0,25 l
Art. Nr. 11 2001

Deckel zur Zuckerdose
cover for sugar bowl
Art. Nr. 11 2201



Zucker- und Teebeutelablagebehälter
tea bag/sugar box
11 x 6 cm
Art. Nr. 11 6011



Suppen-Obertasse mit zwei Henkeln, stapelbar
soup cup with two handles, stackable
0,25 l
Art. Nr. 11 5502



Bowl, stapelbar
bowl, stackable
0,25 l / 9,5 cm
Art. Nr. 11 5003



Zuckerschale, glatt
sugar dish
8 cm
Art. Nr. 11 6004



Zahnstocherbehälter
toothpick holder
6 cm
Art. Nr. 39 4604



Salzstreuer
salt cellar
5 cm
Art. Nr. 11 7500



Pfefferstreuer
pepper pot
5 cm
Art. Nr. 11 7502



Eierbecher, zylindrisch
egg cup, cylindrical
4,5 x 4 cm
Art. Nr. 20 7403



Eierbecher mit Ablage
egg cup
12 cm
Art. Nr. 11 7404



Schüssel rund, stapelbar
bowl, round, stackable
0,25 l, 13 x 4,5 cm
Art. Nr. 11 2900



Schüssel rund, stapelbar
bowl, round, stackable
0,75 l, 16 x 5,5 cm
Art. Nr. 11 2901



Schüssel rund, stapelbar
bowl, round, stackable
1,00 l, 19 x 6 cm
Art. Nr. 11 2902

Die Kombi-Untertasse 15 cm ist passend zu allen Tassen (außer Espresso).
Saucer 15 cm suits to all cups (except espresso).

System Plus



Teller, tief
plate, deep
20 cm
Art. Nr. 11 3421

23 cm
Art. Nr. 11 3416

30 cm
Art. Nr. 45 3319



Platte, oval
platter, oval
23 cm
Art. Nr. 45 3304



Platte, oval
platter, oval
32 cm
Art. Nr. 45 3306



Teller, flach
plate, flat
16 cm
Art. Nr. 11 3422



Teller, flach
plate, flat
26 cm
Art. Nr. 11 3403



Teller, flach
plate, flat
19 cm
Art. Nr. 11 3401



Teller, flach
plate, flat
28 cm
Art. Nr. 11 3412



Teller, flach
plate, flat
20 cm
Art. Nr. 11 3411



Teller, flach
plate, flat
31 cm
Art. Nr. 11 3408



Teller, flach
plate, flat
24 cm
Art. Nr. 11 3417